

Form 9-331
(May 1963)UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPPLICATE*
(Other instructions on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM-0255595

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)1. OIL WELL ☒ GAS WELL ☐ OTHER ☐2. NAME OF OPERATOR
McCulloch Oil & Gas Corporation3. ADDRESS OF OPERATOR
3033 N.W. 63rd; Suite 250-E, Oklahoma City, Okla. 731164. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below.)
At surface

660' FSL & 654' FWL of section

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Monument Draw 6

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Drinkard

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

Sec. 6, T23S-R38E

14. PERMIT NO.

15. ELEVATIONS (Show whether DE, RT, GR, etc.)

3321.3' GR; 3333' KB

12. COUNTY OR PARISH

Lea

13. STATE

New Mexico

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF ☐FRACTURE TREAT ☐SHOOT OR ACIDIZE ☐REPAIR WELL ☐(Other) ☐PULL OR ALTER CASING ☐MULTIPLE COMPLETE ☐ABANDON* ☒CHANGE PLANS ☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐FRACTURE TREATMENT ☐SHOOTING OR ACIDIZING ☐(Other) ☐REPAIRING WELL ☐ALTERING CASING ☐ABANDONMENT* ☐(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

1. Run cmt. retainer on 2 7/8" tbg and set in 8 5/8" csg at 2900'.
2. Load hole and establish pump in rate.
3. Mix and pump 115 sx Class "C" neat cmt. mixed at 14.8 ppg.
4. Pump 43.5 bbls 9 ppg mud-laden fluid.
5. Mix and pump 150 sx Class "C" neat cmt. mixed at 14.8 ppg.
6. Pump 15 bbls mud-laden fluid.
7. Pull out of cmt. retainer, leaving 6 sx of cmt. on top of retainer.
8. Pull and lay down tubing.
9. Cut off 12 3/4" casing and 8 5/8" casing 3' below ground level and spot 10 sx cement from 3' to 30'.
10. Weld on steel plate and erect dry hole marker with well name, number, and date plugged.
11. Clean and restore location.

RECEIVED

MAY 29 1979

U. S. GEOLOGICAL SURVEY
HOBBS, NEW MEXICO

Note: A well bore sketch is attached.

SEE ATTACHED FOR
CONDITIONS OF APPROVAL

18. I hereby certify that the foregoing is true and correct

SIGNED

J.D. Rawdon
J.D. Rawdon

TITLE District Manager


DATE May 24, 1979

(This space for Federal or State office use)

APPROVED BY

CONDITIONS OF APPROVAL, IF ANY:

TITLE



*See Instructions on Reverse Side