

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUBMIT IN TRIPL  
(Other instructions  
reverse side)

Form approved.  
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

NM-14164

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

Wilson Federal Com.

9. WELL NO.

1

10. FIELD AND POOL, OR WILDCAT

Undesignated

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

Sec. 5, 24S, 35E

12. COUNTY OR PARISH 13. STATE

Lea

N.M.

1. OIL WELL ☐ GAS WELL ☒ OTHER

2. NAME OF OPERATOR

Gulf Oil Corporation

3. ADDRESS OF OPERATOR

Box 670, Hobbs, New Mexico 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*  
See also space 17 below.)

At surface

1980' FN& WL Section 5-24S-35E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3455' GL

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON\*

CHANGE PLANS

XX

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT\*

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

14,190' PB. 14,248' TD.

Load tubing and kill well if necessary with 10# brine. Unseat from Otis "WB" packer at 13,700'. Dump 35 sack cement plug on top of packer. Circulate abandonment mud. Pull out with tubing. Run in hole with 7" 26# CIBP on 2-3/8" tubing to top of 5" liner at 11,713'. Set CIBP at approximately 11,700'. Dump 35 sack cement on top of CIBP at 11,700' to 11,537'. Pull up to 9100', lay down tubing. Dump 35 sacks cement plug from 9100' to 8937'. Pull up to 5500', dump 35 sacks cement from 5500' to 5337'. Cut 7" 26# casing at approximately 4500' and recover. Cut 9-5/8" casing at approximately 3500' and recover. Spot 100' cement plug from 50' inside 9-5/8" casing to 50' above cut. Spot 100' cement plug from 900' to 800'. Spot 100' cement plug from 500' to 400'. Spot 50' cement plug from 50' to surface. Install dry hole marker and clean location.

APPROVED SUBJECT TO POSSIBLE FUTURE  
REQUIREMENT THAT PAD AND/OR ROAD  
BE RIPPED AND RELEVELLED

18. I hereby certify that the foregoing is true and correct

SIGNED

*B. J. Bandy*

TITLE

Area Engineer

(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY:

APPROVED

JUL 11 1974

ARTHUR R. BROWN  
DISTRICT ENGINEER

7-9-74