

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE
(Other instructions
verse side)

Budget Bureau No. 1004-0135
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		5. LEASE DESIGNATION AND SERIAL NO. NM-2244
2. NAME OF OPERATOR GETTY OIL COMPANY		6. IF INDIAN, ALLOTTEE OR TRIBE NAME
3. ADDRESS OF OPERATOR P.O. BOX 730, HOBBS, NEW MEXICO 88240		7. UNIT AGREEMENT NAME
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface Unit Letter I, 2180' FSL & 660' FEL		8. FARM OR LEASE NAME Hughes Federal
14. PERMIT NO.		9. WELL NO. 4
15. ELEVATIONS (Show whether DF, RT, GR, etc.) 3333' GR		10. FIELD AND POOL, OR WILDCAT
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 17-23S-37E
		12. COUNTY OR PARISH Lea
		13. STATE NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF <input type="checkbox"/>	PULL OR ALTER CASING <input type="checkbox"/>
FRACTURE TREAT <input type="checkbox"/>	MULTIPLE COMPLETS <input type="checkbox"/>
SHOOT OR ACIDIZE <input type="checkbox"/>	ABANDON* <input checked="" type="checkbox"/>
REPAIR WELL <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
(Other) PLUG AND ABANDON <input type="checkbox"/>	

SUBSEQUENT REPORT OF:

WATER SHUT-OFF <input type="checkbox"/>	REPAIRING WELL <input type="checkbox"/>
FRACTURE TREATMENT <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
SHOOTING OR ACIDIZING <input type="checkbox"/>	ABANDONMENT* <input type="checkbox"/>
(Other) <input type="checkbox"/>	

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.) *

1. Move in rig. Install BOP.
2. Pick up 2 3/8" workstring.
3. GIH with 5 1/2" CIBP on 2 3/8" workstring.
4. Set CIBP at + 3400'.
5. POH with workstring and setting tool.
6. GIH with 2 3/8" workstring open ended.
7. Tag CIBP, pull up and spot 3 sx. of cement on plug, top of cement on plug + 3365'.
8. Pull workstring to + 2500'.
9. Spot 50 sx. cement plug in 5 1/2" casing from + 2500' to 2020'.
10. Pull up to + 1400'.
11. Spot 50 sx. cement plug in 5 1/2" casing from + 1400' to + 920'.
12. Pull up to 600' and spot 20 sx. cement plug from + 600 to + 400'.
13. Pull up and spot 10 sx. cement plug from + 100' to surface.
14. POH.
15. Weld 1" steel plate over casing and install dry hole marker. P/A.

18. I hereby certify that the foregoing is true and correct

SIGNED Dale R. Crockett

TITLE Area Superintendent

DATE 4/30/84

(This space for Federal or State office use)

APPROVED BY P. P. Pritchard

TITLE Area Eng.

DATE 5/8/84

CONDITIONS OF APPROVAL, IF ANY:

0+6-BLM-Roswell 1-Engr. _____ 1-Fil.
*See Instructions on Reverse Side 2-Midland-_____ 1-Foreman_____

RECEIVED

MAY 9 1984

O.C.D.
HOBBY OFFICE