

7. MIRU WL. NU lubricator & test to 3000#. RIR w/gammagun & perf 13,518-532', 13,286-296 13,767-274' (66 total holes). POH. RDWO WL.
8. Sep/flow test well. If well will not flow, swb well to RLA. MIRU stimulation company. 40 surf lines & test to 9000#. Place, maintain & monitor 3000# on annulus. Pump 7000 bbls of MOD 202 acid & .2% corrosion inhibitor. After 10 bbls acid have been pumped space out 90 RCNBS. If ballout occurs, surge balls & continue w/displacement. Displ acid w/65 bbls of 2% KCl wtr. RDWO stimulation company.
9. Sep/flow well back immediately. Place well on production.