

POGO PRODUCING COMPANY
ALLISON FEDERAL COM #1
2310' FNL & 660' FEL Sec. 7
T24S-R35E Lea Co. NM

1. Drill 17- $\frac{1}{2}$ " hole to 500'. Run and set 500' of 13-3/8" 54.5 ST&C casing. Cement with 350 sx. Class "C" + 2% CaCl. Circulate cement to surface.
2. Drill 12- $\frac{1}{4}$ " hole to 5100'. Run and set 5100' of 9-5/8" 40# N-80 ST&C casing. Cement with 1100 sx of light cement. Tail in with 200 sx Class "C" + additives. Circulate cement to surface.
3. Drill 8- $\frac{1}{2}$ " hole to 12,000'. Run and set 12,000' of 7" 26 & 29# P-110 & N-80 Buttress and LT&C casing. Cement with 800 sx of light cement. Tail in with 200 sx of premium cement. Top of cement 4000' \pm
4. Drill 6- $\frac{1}{2}$ " hole to 14,500'. Run and set a 5" 18# P-110 LT&C liner from 14,500' to 11,800' (200' overlap). Cement liner with 200 sx of premium cement. Cement top to be above 11,800'.