

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIPLICATE
(Other Instructions)

Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. UNIT AGREEMENT NAME Cotton Draw Unit
2. NAME OF OPERATOR TEXACO INC.	8. FARM OR LEASE NAME Cotton Draw Unit
3. ADDRESS OF OPERATOR P.O. Box 730, Hobbs, NM 88240	9. WELL NO. 55
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 330' FNL & FEL (Unit Letter A)	10. FIELD AND POOL, OR WILDCAT Paduca Delaware
14. PERMIT NO.	15. ELEVATIONS (Show whether DF, BT, GR, etc.) 3376' DF
	12. COUNTY OR PARISH Lea
	13. STATE NM

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
TEST WATER SHUT-OFF	<input type="checkbox"/>	WATER SHUT-OFF	<input type="checkbox"/>
FRACTURE TREAT	<input type="checkbox"/>	FRACTURE TREATMENT	<input type="checkbox"/>
SHOOT OR ACIDIZE	<input type="checkbox"/>	RECOILING OR ACIDIZING	<input type="checkbox"/>
REPAIR WELL	<input type="checkbox"/>	(Other)	<input type="checkbox"/>
PULL OR ALTER CASING	<input checked="" type="checkbox"/>	REPAIRING WELL	<input type="checkbox"/>
MULTIPLE COMPLETE	<input type="checkbox"/>	ALTERING CASING	<input type="checkbox"/>
ABANDON*	<input checked="" type="checkbox"/>	ABANDONMENT*	<input type="checkbox"/>
CHANGE PLANS	<input type="checkbox"/>		

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

- 1) MIRU PU.
- 2) RU WL trk. Run free pt survey. Cut 4-1/2" csg above free pt w/jet cutter and pull csg. (TOC calc. @ 4150').
- 3) GIH w/WS to top of 4-1/2" csg stub. Ld hle w/salt gel mud consisting of a 10# brine containing 25# gel/bbl.
- 4) Spt 30 sx cmt across 4-1/2" csg stub. (Cmt vol. calc. to cover 50' inside 4-1/2" csg and 50' inside 6-3/4" OH). SION.
- 5) Tag cement plug.
- 6) Spt 50 sx cmt from 1000-900' (top of salt section).
- 7) Spt 40 sx cmt across 7-5/8" csg shoe. (Cmt volume calc. to cover 50' inside 6-3/4" OH & 50' inside 7-5/8" csg).
- 8) Spt 50' plug at surf.
- 9) Cut off WH. Install marker.
- 10) RD PU. Cln locn.

VERBAL APPROVAL BY SHANNON SHAW.

18. I hereby certify that the foregoing is true and correct

SIGNED <u>[Signature]</u>	TITLE <u>Area Manager</u>	DATE <u>11/13/89</u>
(This space for Federal or State office use)		
APPROVED BY <u>[Signature]</u>	TITLE <u>PETROLEUM ENGINEER</u>	DATE <u>11-27-89</u>
CONDITIONS OF APPROVAL, IF ANY:		

*See Instructions on Reverse Side