

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

# NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103  
Supersedes Old  
C-102 and C-103  
Effective 1-1-65

5a. Indicate Type of Lease
State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.

## SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name <i>Tanglie Jack</i>
2. Name of Operator <i>Continental Oil Company</i>	8. Field or Lease Name <i>Tanglie Jack Unit</i>
3. Address of Operator <i>Box 460, Hobbs, New Mexico</i>	9. Well No. <i>1</i>
4. Location of Well UNIT LETTER <i>O</i> , <i>660</i> FEET FROM THE <i>South</i> LINE AND <i>1980</i> FEET FROM THE <i>East</i> LINE, SECTION <i>17</i> TOWNSHIP <i>24-S</i> RANGE <i>37-E</i> N.M.P.M.	10. Field and Pool, or Wildcat <i>Tanglie meter, 7 Rivers Queen</i>
15. Elevation (Show whether DF, RT, GR, etc.) <i>3285' KB</i>	12. County <i>Lea</i>

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work.) SEE RULE 1103.

*It is proposed to plug & abandon this well by the following procedures.*

*Place a 100 sx cmt plug from 3565' (plug back depth) to approx 3225'. Cut 7" casing at approx 1790' and pull. Place a 100 sx plug in & out of 7" stub at 1790'. Spot a 50 sx cmt plug from 1200' to 1150' (around surface casing shoe). Set a 10 sx cmt plug at surface and cap with clay hole marker. Clear location for inspection. Fill well bore with 10# mud between each set of cmt plugs. Work to commence as soon as approval is given. NMOSCC 3 File*

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *[Signature]* TITLE *Administrative Section Chief* DATE *11-5-71*

APPROVED BY *Joe D. Ramey* TITLE *Dist. I, Supv.* DATE *NOV 17 1971*

RECEIVED

MAY 6 1971

OIL CONSERVATION COMM.  
HILLS, N. M.