

UNITED STATES, NEW MEXICO 32240

DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☒ gas ☐ other ☐
well well

2. NAME OF OPERATOR

TEXACO Inc.

3. ADDRESS OF OPERATOR

P. O. Box 728, Hobbs, New Mexico 88240

4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.)

330' FSL & 2310' FWL
(Unit Letter 'N')

AT SURFACE:

AT TOP PROD. INTERVAL:

AT TOTAL DEPTH:

16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO:

SUBSEQUENT REPORT OF:

TEST WATER SHUT-OFF ☐

FRACTURE TREAT ☐

SHOOT OR ACIDIZE ☐

REPAIR WELL ☐

PULL OR ALTER CASING ☐

MULTIPLE COMPLETE ☐

CHANGE ZONES ☐

ABANDON* ☐

(other) OF: Downhole Commingle

5. LEASE

LC-032874 (a)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

G. L. Erwin 'A' Federal

9. WELL NO.

1

10. FIELD OR WILDCAT NAME

Justis Blinberry & Justis
Tubb Drinkard

11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA

Sec. 35, T-24-S, R-37-E

12. COUNTY OR PARISH

13. STATE

Lea

New Mexico

14. API NO.

15. ELEVATIONS (SHOW DF, KDB, AND WD)

3716' (DF)

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

1. Rigged up.

2. Set CIBP in Drinkard string @ 5710' and spot 40' cement on plug. Set CIBP @ 5000' and spot 40' cement on plug. Set COB @ 4450' and spot 40' cement on plug. Abandon Drinkard string, 5-4-84.

3. Clean out Devonian string.

4. Perforate Devonian String W/4-JSFF from 6100-6110'; 5995-6005, & 5640-5650'.

5. Set CIBP @ 6130 and prk @ 6051'. Acidize 2 7/8" perms 6100'-6110'

(Tubb Drinkard Zone) W/500 gals 15% NEFE Acid. Flush W/18 Bbls fresh water.

6. Reset RBP @ 6050' and prk @ 5954'. Acidize Commingle perms 5995-6005 W/500 gals 15% NEFE Acid. Flush W/18 bbls fresh water.

7. Reset RBP @ 5750 and prk @ 5535'. Acidize perms 5640-5650 (Blinberry) W/500 gals 15% NEFE Acid. Flush W/18 bbls fresh water.

8. Pull RBP AND PKR. Set 2 1/16" tubing @ 6164'. Install pumping equipment.

Subsurface Safety Valve: Manu. and Type

Set @ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

Asst. Dist. Mgr.

DATE

6-6-84

(This space for Federal or State office use)

APPROVED BY

TITLE

P.E.

DATE

6/13/84

CONDITIONS OF APPROVAL, IF ANY:

Order NO. 343

9. On 24 Hour potential ending 9:00 AM, 5-28-84, well pumped 37 B0 and 76 BW with GOR of 3729. Well completed as downhole commingle of Blinebry and Tubb Drinkard.