

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	
7. Unit Agreement Name	
8. Farm or Lease Name Hodges B	
9. Well No. 3	
10. Field and Pool, or Wildcat N. Justis-Fuss. Drink-Bline	
12. County Lea	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator CITIES SERVICE OIL COMPANY
3. Address of Operator P.O. Box 69, Hobbs, New Mexico 88240
4. Location of Well UNIT LETTER L , 1880 FEET FROM THE South LINE AND 330 FEET FROM THE West LINE, SECTION 1 TOWNSHIP 25S RANGE 37E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3118' GR

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

TD 7224', Fusselman 7036--7180', Drinkard 6067--6100', Blinebry 5082--5594. We propose to plug and abandon this triple completed well in the following manner:

1. Set CIBP above Fusselman perforations at approximately 7010'.
2. Dump 4 sack cement plug on top of CIBP.
3. Set CIBP above Drinkard perforations at approximately 6040'.
4. Dump 4 sack cement plug on top of CIBP.
5. Set CIBP above Blinebry perforations at approximately 5055'.
6. Dump 4 sack cement plug on top of CIBP.
7. Load hole with mud laden fluid.
8. Shoot off and recover approximately 4000' 7" casing. (Top of cement 4010', base of San Andres 4657').
9. Spot a 35 sack cement plug $\frac{1}{2}$ in and $\frac{1}{2}$ out of the 7" casing stub.
10. Spot a 25 sack cement plug $\frac{1}{2}$ in and $\frac{1}{2}$ out of the 9 5/8" intermediate shoe.
11. Dump 10 sack cement plug in top of 9 5/8" casing from ground level.
12. Install 4" dry hole marker and clean location of all materials and debris.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED _____

TITLE **Dist. Admin. Supervisor**

DATE **1-14-72**

Orig. Signed by
Joe D. Ramey
Dist. 1, Supv.

APPROVED BY _____

TITLE _____

DATE **JAN 19 1972**

CONDITIONS OF APPROVAL, IF ANY: