

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	
7. Unit Agreement Name	
8. Farm or Lease Name Hodges B	
9. Well No. 4	
10. Field and Pool, or Wildcat N. Justis-Dev. & Tubb Drink	
12. County Lea	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT --" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>
2. Name of Operator CITIES SERVICE OIL COMPANY
3. Address of Operator P.O. BOX 69, Hobbs, New Mexico 88240
4. Location of Well UNIT LETTER M , 990 FEET FROM THE South LINE AND 660 FEET FROM THE West LINE, SECTION 1 TOWNSHIP 25S RANGE 37E NMPM.
15. Elevation (Show whether DF, RT, GR, etc.) 3116' GR

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:



REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

TD 8982', Devonian 7010--7146', Tubb-Drinkard 6099--6132'. We propose to plug and abandon this dual completed well in the following manner.

1. Set CIBP above Devonian perforations at approximately 6985'.
2. Dump 4 sack cement plug on top of CIBP
3. Set CIBP above Tubb-Drinkard perforations at approximately 6075'.
4. Dump 4 sack cement plug on top of CIBP.
5. Load hole with mud laden fluid.
6. Shoot off and recover approximately 5500' of 7" casing (Top of cement 5550').
7. Spot a 35 sack cement plug $\frac{1}{2}$ in and $\frac{1}{2}$ out of 7" casing stub.
8. Spot a 35 sack cement plug at the base of the San Andres (approx. 4689')
9. Spot a 25 sack cement plug $\frac{1}{2}$ in and $\frac{1}{2}$ out of the 9 5/8" intermediate shoe.
10. Dump a 10 sack cement plug in top of 9 5/8" casing
11. Install 4" dry hole marker and clean location of all materials and debris.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED  TITLE Dist. Admin. Supervisor DATE 1-14-72
APPROVED BY  TITLE DISTRICT I DATE JAN 16 1972
CONDITIONS OF APPROVAL, IF ANY: