

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name	
2. Name of Operator Cities Service Company		8. Farm or Lease Name Hodges B	
3. Address of Operator P.O. Box 1919 Midland, TX 79702		9. Well No. 2	
4. Location of Well UNIT LETTER <u>L</u> <u>1980</u> FEET FROM THE <u>South</u> LINE AND <u>330</u> FEET FROM THE <u>West</u> LINE, SECTION <u>1</u> TOWNSHIP <u>25S</u> RANGE <u>37E</u> NMPM.		10. Field and Pool, or Wildcat Justis Fusselman, North	
15. Elevation (Show whether DF, RT, GR, etc.) 3134.5' GR		12. County Lea	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☐
CHANGE PLANS ☐
OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOB ☐
OTHER Squeeze casing leak ☒
ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

SEE ATTACHMENT

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature]

TITLE Region Operations Mgr.

DATE 8/31/79

Orig. Signed by

Jerry Sexton

Dist 1, Supv.

APPROVED BY

TITLE

DATE SEP 6 1979

CONDITIONS OF APPROVAL, IF ANY

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name	
2. Name of Operator Cities Service Company		8. Farm or Lease Name Hodges B	
3. Address of Operator P.O. Box 1919 Midland, TX 79702		9. Well No. 2	
4. Location of Well UNIT LETTER <u>L</u> <u>1980</u> FEET FROM THE <u>South</u> LINE AND <u>330</u> FEET FROM THE <u>West</u> LINE, SECTION <u>1</u> TOWNSHIP <u>25S</u> RANGE <u>37E</u> NMPM.		10. Field and Pool, or Wildcat Justis Fusselman, North	
15. Elevation (Show whether DF, RT, GR, etc.) 3134.5' GR		12. County Lea	

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐

PLUG AND ABANDON ☐
CHANGE PLANS ☐

OTHER Squeeze casing leak ☒

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐
COMMENCE DRILLING CPNS. ☐
CASING TEST AND CEMENT JOB ☐
OTHER ☐

ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.
TD 8457'

1. MIRU - install BOP & pull rods & tbg.
2. Run 6-1/8" bit & scraper to PBTD.
3. RIH with tbg & RBP.
4. Set RBP @ 7175'. Pick up & spot 225' sand on top of RBP to 6950' to cover Fusselman perms. POOH.
5. RIH w/RTTS & set @ 6700'. Pressure annulus to 1000# pressure tbg & establish injection rate. Cmt squeeze csg leak with low pressure squeeze.
6. Release RTTS & reverse cmt out tbg - pick up two stands & set RTTS. Pressure annulus & tbg & WOC 24 hrs.
7. POOH w/RTTS & RIH w/rock bit & drill out to top of sand.
8. Test csg to 1000# resqueeze if necessary.
9. RIH, wash out sand, & retrieve RBP.
10. Run 2-3/8" EUE tbg & swab test.
11. If needed, acidize Fusselman perms & swab test.
12. Run pump, rods, & HOB.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature]

TITLE Region Operations Mgr.

DATE 7/24/79

APPROVED BY Jerry Sexton

TITLE Dist 1, Supv.

CONDITIONS OF APPROVAL, IF ANY:

DATE JUL 27 1979