

Submit 3 Copies To Appropriate District
Office:
District I
1625 N. French Dr., Hobbs, NM 87240
District II
811 South First, Artesia, NM 87210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
2040 South Pacheco, Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised March 25, 1999

OIL CONSERVATION DIVISION
2040 South Pacheco
Santa Fe, NM 87505

WELL API NO. 30-025-11542
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name: Langlie Mattix Queen Unit
8. Well No. 1
9. Pool name or Wildcat Langlie Mattix, 7 Rivers-Q-Grayburg

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH
PROPOSALS.)

1. Type of Well:
Oil Well ☒ Gas Well ☐ Other

2. Name of Operator

Prize Operating Company

3. Address of Operator

3500 William D. Tate, Suite 200, Grapevine, Texas 76051

4. Well Location

Unit Letter **L**: **1650** feet from the **South** line and **330** feet from the **West** line

Section **11** Township **25S** Range **37E** NMPM County **Lea**

10. Elevation (Show whether DR, RKB, RT, GR, etc.)

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

Prize Operating Company respectfully request approval to Plug and Abandon the above mentioned well. We had received OCD approval to TA the well (11-3-2000), but were unsuccessful in this process. Per OCD instructions, if the well was not TA'd then the well was to be P & A. Please find attached P & A procedure and well schematic. If you have any questions, please contact Mr. Bill Kreimler (engineer) at 817-424-0480.

THIS NOTICE OF INTENTION TO
PLUG AND ABANDON THE ABOVE
MENTIONED OPERATIONS FOR THE C-103
TO BE APPROVED.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Don Aldridge TITLE Regulatory Analyst DATE 11-21-2000

Type or print name Don Aldridge Telephone No. 817-424-0454

(This space for State use)

APPROVED BY _____ TITLE _____ DATE _____
Conditions of approval, if any:

**Langlie Mattix Queen Unit #1
Plug and Abandon**

Procedure:

1. MIRU Workover Rig. Tag CIBP at +/- 3050'. Spot 35' of cement on top.
2. RIH with tubing and tag cement plug. Circulate hole with 10 # Brine And gel.
3. ~~Spot cement plug from 2500' - 2400'~~
PERF @ 850 50' OUT IN TAG PLUG @ 800'
4. ~~Perforate casing at +/- 250' and squeeze with 50 sacks cement. Spot 10 sacks surface plug.~~
SPOT CEMENT PLUG F/264' - 164' - TAG
5. Cut casing and cap well.
6. Set dry hole marker and clean location.

"CURRENT"

Langlie Matrix Queen UT #1

API 30-625-11542

Sec 11 T.25-S R-37 E

L 1650' FSL & 330' FWL

8 5/8" @ 214'
150 SX (surface)

5 1/2" - 17# @ 3148'
450 SX

(open Hole)
3148-3410

TD 3410'

CIBP @ 3050' w/2 SX Cmt

"PROPOSED"

Langlie Matrix Queen UT #1

API 30-025-11542

Sec 11 T.25-S R-37E

L 1650' FSL & 330' FWL

