

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-73

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	
NM 13010	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Gas Well in Oil Pool		7. Unit Agreement Name
2. Name of Operator American Exploration Company		8. Farm or Lease Name Alston
3. Address of Operator 2100 RepublicBank Center, Houston, Texas 77002		9. Well No. 1
4. Location of Well UNIT LETTER <u>D</u> <u>330</u> FEET FROM THE <u>North</u> LINE AND <u>330</u> FEET FROM THE <u>West</u> LINE, SECTION <u>26</u> TOWNSHIP <u>25S</u> RANGE <u>37E</u> N.M.P.M.		10. Field and Pool, or WHdcat Langlie Mattix SR-OU-CB
15. Elevation (Show whether DF, RT, GR, etc.)		12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPER. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

American Exploration Company proposes to plug the subject well as follows:

RU WSU and lay down production equipment. Set CIBP 50' above casing shoe. Cap with 50' cement. Spot 150' plug across casing stub (75' in/ 75' out). Set 150' plug across 8-5/8" shoe (75' in / 75' out). Perforate at 380' and circulate cement to surface. Cut casing off 4' below ground level. Spot 20' plug at surface. Weld cap on casing with required information attached. Clean location.

THE COMMISSION ORDER IS DATED 24
OCTOBER 1988 TO THE TITLING OF
RECORDS RELATIONS FOR THE C-103
TO BE APPROVED.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Marty McClanahan TITLE Production Dept. DATE 9/14/88

ORIGINAL SIGNED BY JERRY SEXTON
DISTRICT 1 SUPERVISOR

APPROVED BY _____ TITLE _____ DATE SEP 18 1988

CONDITIONS OF APPROVAL, IF ANY:

RECEIVED

SEP 16 1988

CCC
HOLLAND OFFICE