

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPlicate*
(Other instruction on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input checked="" type="checkbox"/> OTHER Shut-In		5. LEASE DESIGNATION AND SERIAL NO. LC 034117(a)	
2. NAME OF OPERATOR Atlantic Richfield Company		6. IF INDIAN, ALLOTTEE OR TRIBE NAME	
3. ADDRESS OF OPERATOR P. O. Box 1978, Roswell, New Mexico 88201		7. UNIT AGREEMENT NAME	
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.* See also space 17 below.) At surface 2310' FSL & 330' FWL		8. FARM OR LEASE NAME Crosby "A"	
14. PERMIT NO.		9. WELL NO. 2	
15. ELEVATIONS (Show whether DF, RT, CR, etc.) 3022' GR		10. FIELD AND POOL, OR WILDCAT Jalmat-Yates	
		11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 28, T25S, R37E	
		12. COUNTY OR PARISH Lea	
		13. STATE N.M.	

16.

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

X

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

This well was shut in 4/16/50 as non-commercial. No remedial possibilities exist. We propose to P & A as outlined below:

1. Set 7" 24# CIBP @ 2500' and cap w/25 sx (100') of cement.
2. Perforate 7" casing w/4 holes @ 1325' and pump in 100 sx of cement, leaving 100' of cement inside 7" from 1225-1325'.
3. Place 10 sk cement plug in top of well.
4. Erect dry hole marker. Clear and level location.

Note: 9#/gal gel mud will be left between all cement plugs.

13" and 9-5/8" casing strings will remain intact.

18. I hereby certify that the foregoing is true and correct

SIGNED

R.D. Lretches

TITLE

Dist. Drlg. Supervisor

DATE

4/22/71

(This space for Federal or State office use)

APPROVED BY

TITLE

APPROVED
APR 23 1971R. BROWN
DISTRICT ENGINEER

DATE

APR 23 1971

*See Instructions on Reverse Side

RECEIVED

APR 27 1971

OIL CONSERVATION C. A.
HOUSTON, TX