


UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT



FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

Lease Designation and Serial No.  
LC-054667

**SUNDRY NOTICES AND REPORTS ON WELLS**

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals.

**SUBMIT IN TRIPLICATE**

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Meridian Oil Inc.

3. Address and Telephone No.

P. O. Box 51810, Midland, TX 79710 (915)688-6899

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

P, 600 FSL 990 FEL, Sec. 33, T-25-S, R-37-E

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

Gregory A #6

9. API Well No.

10. Field and Pool, or Exploratory Area

Langlie-Mattix(7R,Q,GB)

11. County or Parish, State

Lea, NM

12. CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent  
☐ Subsequent Report  
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment  
☐ Recompletion  
☐ Plugging Back  
☐ Casing Repair  
☐ Altering Casing  
☐ Other

- ☐ Change of Plans  
☐ New Construction  
☐ Non-Routine Fracturing  
☐ Water Shut-Off  
☐ Conversion to Injection  
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Sundry of Notice of Intent to Plug and Abandon previously approved 11-20-90--Work was not done. Re-submitting Sundry to Plug and Abandon.

Plug and Abandonment Procedure:

Notify BLM prior to starting work. RIH and sting into cement retainer at 2387'. Squeeze under retainer with 100 sxs of Class C cement with 2% CaCl<sub>2</sub> added. Cap with 12 sxs of cement. Spot 9 ppg gelled brine at 965' to 2320'.

Establish pump-in rate. RIH with retainer; set at 965'; squeeze under retainer with 30 sxs of cement. Cap with 10 sxs of cement; spot 9 ppg gelled brine from 500' to 905'. Pull up to 500'; circulate cement to surface using 90 sxs. Cut off casing 3' below ground level. Install P&A monument. Clear, rip, and reseed location.

14. I hereby certify that the foregoing is true and correct

Signed

*Pat Henry*

Title

Production Assistant

Date

11-19-92

(This space for Federal or State office use)

PETROLEUM ENGINEER

Approved by

*David H. Glass*

Title

Date

12-28-92

Conditions of approval, if any:

**RECEIVED**

**DEC 3 1 1992**

**OCD HOBBS OFFICE**