

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

FORM APPROVED  
Budget Bureau No. 1004-0135  
Expires: March 31, 1993

5. Lease Designation and Serial No.

LC-032510-8

6. If Indian, Ailotee or Tribe Name

**SUNDRY NOTICES AND REPORTS ON WELLS**

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.  
Use "APPLICATION FOR PERMIT—" for such proposals

**SUBMIT IN TRIPLICATE**

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

Meridian Oil Inc.

3. Address and Telephone No.

P.O. Box 51810, Midland, TX 79710 (915-688-6800)

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

Unit P 990 FSL & 660 FEL  
Sec. 35 T-25-S, R-37-E

8. Well Name and No.

L.L. Gregory #1

9. API Well No.

10. Field and Pool, or Exploratory Area

Langlie Mattix

11. County or Parish, State

Lea

**CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA**

TYPE OF SUBMISSION

☒ Notice of Intent

☐ Subsequent Report

☐ Final Abandonment Notice

TYPE OF ACTION

☒ Abandonment

☐ Recompletion

☐ Plugging Back

☐ Casing Repair

☐ Altering Casing

☐ Other

☐ Change of Plans

☐ New Construction

☐ Non-Routine Fracturing

☐ Water Shut-Off

☐ Conversion to Injection

☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

1. Notify Hobbs BLM office prior to starting work. MIRU PU. ND wellhead, NU BOP. Deliver workstring to location. Pick up workstring and RIH with tubing and sting into cement retainer at 3030'. (GL) Retainer was set by Schlumberger in 1990 and is believed to be an Elder retainer. Squeeze under retainer with 35 sxs of cement. Sting out of retainer and spot 5 sxs of cement on retainer. Pull up above cement and circulate hole with 9 ppg gelled brine.
2. Pull up to 2230' and set a cement plug across the base of the salt at 2110' to 2230' using 15 sxs of cement. Pull up to 1120' and set a cement plug across the top of the salt at 1000' to 1120' using 15 sxs of cement. Pull up to 310' and circulate cement to surface using 35 sxs. POOH laying down. RDMO PU.
3. Cut off casing 3' below ground level and install P & A marker. Clear, rip, and reseed location

14. I hereby certify that the foregoing is true and correct

Signed

Title

Production Assistant

Date

12-7-92

(This space for Federal or State office use)

Approved by

Title

Date

Conditions of approval, if any:

12/30/92