

STATE OF NEW MEXICO  
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

L CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-228-1	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator Gulf Oil Corporation		8. Farm or Lease Name Vinson Ramway (NCT-B)
3. Address of Operator P. O. Box 670, Hobbs, NM 88240		9. Well No. 12
4. Location of Well UNIT LETTER L 2310 FEET FROM THE South LINE AND 990 FEET FROM THE West LINE, SECTION 36 TOWNSHIP 25S RANGE 37E N.M.P.M.		10. Field and Pool, or Tract Justis Blinbry
15. Elevation (Show whether DF, RT, GR, etc.) 3027' GL		12. County Lea

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐  
TEMPORARILY ABANDON ☐  
PULL OR ALTER CASING ☐

PLUG AND ABANDON ☐  
CHANGE PLANS ☐

REMEDIAL WORK ☐  
COMMENCE DRILLING OPNS. ☐  
CASING TEST AND CEMENT JOB ☐  
OTHER ☐

ALTERING CASING ☐  
PLUG AND ABANDONMENT ☐

OTHER Perf & Circulate cement ☒

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103. POH with with tubing, rods & pump.  
Set RBP at 2500', cap with 10' + frac sand. Perforate at 1175' with (4) 1/2" JH with 90° phasing. Establish circulation down 7" casing and out 7" - 9-5/8" annulus with fresh water. Set cement retainer at 1125'; re-establish circulation. Cement with 200 sacks Class "C" cement + 2% CaCl<sub>2</sub>. Put out of retainer & reverse excess cement. Drill up retainer and cement. Pressure test casing to 500#. Swab. Recover RBP; rerun tubing, rods & pump. Hang well on.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED R.D. Pate TITLE Area Engineer DATE 8-4-80

APPROVED BY \_\_\_\_\_ TITLE \_\_\_\_\_ DATE \_\_\_\_\_

CONDITIONS OF APPROVAL, IF ANY: