

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input type="checkbox"/> Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Water Injection Well	7. Unit Agreement Name West Dollarhide Queen Sand Unit
2. Name of Operator Skelly Oil Company	8. Farm or Lease Name West Dollarhide Queen Sand Unit
3. Address of Operator P. O. Box 1351, Midland, Texas 79701	9. Well No. 11
4. Location of Well UNIT LETTER E 990 FEET FROM THE West LINE AND 2310 FEET FROM THE North LINE, SECTION 30 TOWNSHIP 24S RANGE 38E NMPM.	10. Field and Pool, or Wildcat Dollarhide Queen
15. Elevation (Show whether DF, RT, GR, etc.) 3126' GR	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well is in an area that has not responded to waterflood operations. In order to reduce operating costs, we propose to plug and abandon the well as follows:

- 1) Move in pulling unit. Pull tubing and packer.
- 2) Set 5-1/2" bridge plug at 3670'.
- 3) Circulate hole with 10.2# mud.
- 4) Spot 15 sacks cement on top of bridge plug.
- 5) Spot 100 sacks cement 980-1750' across top of salt section.
- 6) Spot 10 sack cement plug at surface.
- 7) Set marker.

All intervals not cemented will be filled with 10.2# mud.

20 m. notice

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED J. R. Avent J. R. Avent Dist. Admin. Coordinator DATE March 4, 1973

APPROVED BY Joe D. Hamey TITLE Dist. Admin. Coordinator DATE March 4, 1973
CONDITIONS OF APPROVAL, IF ANY: