

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator		8. Farm or Lease Name
3. Address of Operator		9. Well No.
4. Location of Well		10. Field and Pool, or Wildcat
15. Elevation (Show whether DF, RT, GR, etc.)		12. County

UNIT LETTER L 990 FEET FROM THE West LINE AND 1650 FEET FROM THE South LINE, SECTION 30 TOWNSHIP 24S RANGE 38E NMPM.

West Dollarhide Queen Sand Unit
West Dollarhide Queen Sand Unit
P. O. Box 1351, Midland, Texas 79701
Dollarhide Queen
3122' DF
Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

This well has not responded to waterflood operations. In order to reduce operating costs, we propose to plug and abandon the well as follows:

- 1) Move in pulling unit. Pull rods, tubing and packer.
- 2) Set 7" bridge plug at 3630'.
- 3) Circulate hole with 10.2# mud.
- 4) Spot 15 sacks cement on top of bridge plug.
- 5) Spot 100 sacks cement 1000-1460' across top of salt section.
- 6) Spot 10 sack plug at surface.
- 7) Set marker.

All intervals not cemented will be filled with 10.2# mud.

24 1/2 no hole

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED	J. R. Avent	TITLE	Dist. Admin. Coordinator	DATE	March 4, 1973
Orig. Signed by		Joe D. Ramey		DATE	
APPROVED BY		Dist. Supv.		DATE	
CONDITIONS OF APPROVAL, IF ANY:					