Form Approved. Budget Bureau No. 42-R1424

DISTRICT ENGINEER

Form 9-331 Dec. 1973

UNITED STATES COPY TO O. C. C.5. LEASE

DEPARTMENT OF THE INTERIOR	+c-064052 NM 10186
GEOLOGICAL SURVEY	6. IF INDIAN, ALLOTTEE OR TRIBE NAME
W1010 W.C.	
SUNDRY NOTICES AND REPORTS ON WELLS	7. UNIT AGREEMENT NAME
SUIVUKT INUTICES AND REPORTS ON WELLS	West Dollarhide Drinkard Unit
(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9–331–C for such proposals.)	8. FARM OR LEASE NAME
1. oil 🖂 gas 🗇	West Dollarhide Drinkard Unit
well M well other	9. WELL NO.
2. NAME OF OPERATOR	48 .20 ∑ 48%
Getty Oil Company	10. FIELD OR WILDCAT NAME
3. ADDRESS OF OPERATOR	Dollarhide Tubb-Drinkard
P. O. Box 730, Hobbs, New Mexico 88240	11. SEC., T., R., M., OR BLK. AND SURVEY OR
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17	AREA SEES 1 SEES
below.) AT SURFACE: ULC, 990' FNL + 2310' FNL	31-245-38E
	12. COUNTY OR PARISH 13. STATE
AT TOP PROD. INTERVAL: AT TOTAL DEPTH:	Lea New Mexico
	14. API NO. 음음으럼 및 호텔들인
16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA	AF FIEWATIONS COLLOW DE LADO MAD
REPORT, OR OTHER DATA	15. ELEVATIONS (SHOW DF, KDB, AND WD)
REQUEST FOR APPROVAL TO: SUBSEQUENT REPORT OF:	3//3-10F
TEST WATER SHUT-OFF	
FRACTURE TREAT / [] 1-A.B. CARY-MIDLAND	
SHOOT OR ACIDIZE	
NCIAIN WELL 1)	
PULL OR ALTER CASING 1-C.King Sten, FOREMAN MULTIPLE COMPLETE 1-FILE CHANGE ZONES 1Q - WIO'S -I LST ATTRACTURE	
CHANGE ZONES	,WIO's -LIST ATTACHED
ABANDON" LI-BH.FIELD	CLERK
(other) Recement Casing	
17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly stat	e all pertinent details, and give pertinent dates,
including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*	
measured and true vertical depths for all markers and zones pertiner	it to this workly
 Rig up pulling unit. 	
2. Pull rods and pump.	
3. Install BOP and pull tubing.	
4. Run retrievable BP to approximately 6000'. Test BP and casing to 1000 psi	
5. Spot 10' of sand on top of BP.	
6. Run cement bond log 6000' to surface.	
7. Perforate and cement squeeze intervals not adequately cemented.	
8. WOC 24 hrs.	
9. Drill out cement and test casing to 1000	ps1.
10. Wash sand off BP and retrieve. 11. Run tubing, rods, and pump and place back on production	
11. Run tubing, rods, and pump and place back	k on production
· ·	
Subsurface Safety Valve: Manu. and Type	Set @ Ft.
18. I hereby certify that the foregoing is true and correct	
SIGNED Area Supt	DATE
Tale R Crockett (This space for Federal or State of	fice use)
tinis space for recerai or State of	
APPROVED BY TITLE CONDITIONS OF APPROVAL, IF ANY:	ADDDOVED
CONDITIONS OF AFFROYAL IF ANT.	ALLIOAFD
	2
	1 1 HUG & 1 19/8 (1) / 1
*See Instructions on Reverse	Side JAMES F. SIMS