

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION
P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO. 30-025-12342
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. B-1732
7. Lease Name or Unit Agreement Name WEST DOLLARHIDE DRINKARD UNIT
8. Well No. 40
9. Pool name or Wildcat DOLLARHIDE TUBB/DRINKARD

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER	
2. Name of Operator TEXACO EXPLORATION AND PRODUCTION INC.	
3. Address of Operator PO BOX 3109; MIDLAND, TEXAS 79702	
4. Well Location Unit Letter <u>C</u> : <u>660</u> Feet From The <u>NORTH</u> Line and <u>660</u> Feet From The <u>EAST</u> Line Section <u>33</u> Township <u>24-S</u> Range <u>38-E</u> NMPM LEA County	
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3193' GL, KB=14'	

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 1) INFORM NMOC D 24 HOURS PRIOR TO COMMENCEMENT OF PLUGGING.
- 2) PULL TUBING AND PUMP. NU BOP. CUT TUBING @ 6600' AND PULL. TIH WITH WASHPIPE AND FISHING TOOLS AND CLEAN JUNK OUT OF HOLE.
- 3) TIH WITH BIT AND COLLARS. DRILL OUT SCALES TO 6840' PETD. CIRC CLEAN.
- 4) GIH WITH 5" RETAINER AND SET AT 6350'. CIRCULATE CASING WITH 10# MJD.
- 5) SQUEEZE LINER PERFS WITH 100 SX CLASS "C" CEMENT. SPOT 50' CEMENT ON TOP.
- 6) LOCATE HOLES AND/OR WATER FLOWS ABOVE DRINKARD WITH LOG/PACKER. IF NECESSARY, SET CIBF @ 4000' (BASE OF QUEEN). PUMP 25SX FROM 4000'-3750'.
- 7) PUMP 25SX FROM 2750'-2500' ACROSS BASE OF SALT SECTION. PUMP 25SX FROM 1300'-1050' ACROSS TOP OF SALT SECTION. PUMP 30SX FROM 350' TO THE SURFACE.
- 8) REFILL CASING ANNULUS FROM SURFACE WITH 1" TUBING IF NECESSARY.
- 9) CUT OFF WELLHEAD AND INSTALL MARKER. CLEAN LOCATION AND RESTORE SURFACE.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE R.J. Harding III TITLE OPERATIONS ENGINEER DATE 2/13/96
TYPE OR PRINT NAME R.J. HARDING III TELEPHONE NO. 915-688-4816

(This space for State Use)

APPROVED BY _____ TITLE _____ DATE FEB 11 1996

CONDITIONS OF APPROVAL, IF ANY: