

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUNDRY NOTICES AND REPORTS ON WELLS

Do not use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: September 30, 1990

5. Lease Designation and Serial No.
LC - 032650b

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.
A.B. Coates C #25

9. API Well No.
30 - 025 - 20060

10. Field and Pool, or Exploratory Area
South Justis BL, TD

11. County or Parish, State
Lea County, NM

89745
11/1/92

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other
☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection

(Note: Report results of multiple completion on Well Completion or
Recompletion Report and Log form.)

3. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled,
give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

- 1) Inform BLM 24 hours prior to commencement of plugging.
- 2) MIRU. Install BOP on Blinebry string. GIH with bit and casing scraper. Clean casing down to tubing stop at 5151'. POH. Move BOP to Drinkard string.
Clean hole to approximately 5500'. POH.
Drinkard (X), West String:
- 3) GIH with work string and set retainer at 5000'. Pump 55 sx class 'H' cement, sting out and spot 5 sx on top. POH.
- 4) GIH and load string with 21 Bbls salt gel mud; 10# brine and 25# gel/ Bbl. Fill string to TOC at 1400'.
- 5) Pump 5 sx plug from 2235'-2435' across base of salt section. WOC. If BLM requires plug to be tagged, then pump 18 sx more and fill to TOC. POH.
Move BOP to Blinebry string.
Blinebry (Y), East String:
- 6) By wireline, set CIBP at 5000' or across from retainer in other string. By bailer, spot 2 sx on top. POH.
- 7) GIH and load string with 21 Bbls salt gel mud; 10# brine and 25# gel/ Bbl. Fill string to TOC at 1400'. Adjust mud volumes as needed, since the 2 7/8" casing strings will be cut off.
- 8) Pump 5 sx plug from 2235'-2435' across base of salt section. WOC. If BLM requires plug to be tagged, then pump 18 sx more and fill to TOC. POH.
- 9) By wireline, jet cut both strings at approximately 1390'.
- 10) Circulate 110 Bbls mud and fill casing to surface. Pump 37 sx cement from 1470'-1350' inside of and on top of casing stubs.
- 11) Tag intermediate plug with WS. Pump 35 sx cement from 943'-843' in 8-5/8" casing across surface shoe. WOC. Tag plug and spot 33 sx from 100' to surface.
Cut off wellhead and install dry hole marker. Clean location.
- 12) Restore surface as per Federal requirements.

I hereby certify that the foregoing is true and correct

Signed [Signature] Title Production Engineer

Date 10-06-92

(This space for Federal or State office use)

Approved by
Conditions of approval, if any:

Title

Date 10/20/92

- SEE ATTACHED -

18 U.S.C. Section 1001, makes it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements
presentations as to any matter within its jurisdiction.

*See Instruction on Reverse Side