Form 9-331 (May 1966)	UNITED STATE DEPARTMENT OF THE I GEOLOGICAL SUF	INTERIOR	SUBMIT IN TRIPLICAT (Other instructions on verse side)	5. LEASE DESIGNATION AND SERIAL NO.
CD0 not use this	JDRY NOTICES AND REPORT s form for proposals to drill or to deeper Use "APPLICATION FOR PERMIT-"	ORTS ON	WELLS a different reservoir. s.)	6. IF INDIAN, ALLOTTIE OR TRIBE NAME
I. GIL WEYL GAS WELL OTHER Water Injection Well 2. NAME OF OPERATOR				7. UNIT AGREEMENT NAME Stuart Langlie Mattix 8. FARM OR LEASE NAME
GULF OIL CORPORATION				Unit
P. O. BC 4. LOCATION OF WELL (See also space 17 bel At surface	ox 670, Hobbs, New Mexic	co 88240 with any State	requirements.*	9. WELL NO. 127 10. FIELD AND POOL, OR WILDCAT Langlie Mattix 11. SEC., T., E., M., OR BLK. AND SUBVET OR AREA
14. PERMIT NO.	14. PERMIT NO. 15. ELEVATIONS (Show whether DF, RT, GR, etc.)			Sec 10, T-25S, R-37E 12. COUNTY OB PARISEL 13, STATE
		3143' (GL	Lea New Mexico
16.	Check Appropriate Box To Inc	dicate Nature	of Notice, Report, or	Other Data
NOTICE OF INTENTION TO: SUBSEQU			QUENT REPORT OF:	
TEST WATER SHUT-O FRACTORE TREAT SHOOT OF ACIDIZE REPAIR WELL	MULTIPLE COMPLETE	X	WATER SHUT-OFF FRACTURE TREATMENT SHOOTING OR ACIDIZING (Other)	REPAIRING WELL ALTERING CASING ABANDONMENT*
(Other)	R COMPLETED OPERATIONS (Clearly state al	l uartinent dutul	Completion or Recon	ts of multiple completion on Well apletion Report and Log form.)

6. DESCRIBE ENDOORSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)^{*}

3550' TD

Pull injection equipment. Set CIBP @ approximately 3200' and cap with 35' cement. Test CIBP to 500 psi. Spot abandonment mud to 1400'. Perforate at approximately 1375' with (2) 1/2" jet holes. Run packer to approximately 1300'. Circulate out 5-1/2" - 8-5/8" annulus. Pull packer. Set cement retainer at approximately 1300' and cement with 400 sacks. Run temperature survey to determine top of cement, if necessary. Leave two to three sacks of cement on top of retainer. Spot abandonment mud from 1280' to 50'. Spot cement plug from 50' to surface. Install dry hole marker. Clear and clean location.

SEE ATTACHED FOR O. DITIONS OF APPROVAL	R = 1578
	U. S. G. OLDGICAL SURVEY HOB ~ JEW MEXIC
IN I horeby certify that the foregoing is true and correct SIGNED	APPROVED DATE 07-17-78
APPROVED BY TITLE CONDITIONS OF APPROVAL, IF ANY:	APPRUVED AS AMENDED JUL 20 1973 DATE
*See Instructions	on Reverse SCHING DISTRICT ENGINEER
