

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEYSUBMIT IN TRIPLICATE*
(Other instruction on re-
verse side)Form approved.
Budget Bureau No. 42-R1424.

5. LEASE DESIGNATION AND SERIAL NO.

LC 067968

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME

J. H. McClure "A"

9. WELL NO.

22

10. FIELD AND POOL, OR WILDCAT

West Dollarhide Dev.

11. SEC., T., R., M., OR BLK. AND
SURVEY OR AREA

30-24S-38E

12. COUNTY OR PARISH 13. STATE

Lea

N.M.

1. TA
OIL WELL ☒ GAS WELL ☐ OTHER

2. NAME OF OPERATOR

Atlantic Richfield Company

3. ADDRESS OF OPERATOR

P. O. Box 1710, Hobbs, New Mexico 88240

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*

See also space 17 below.)
At surface

2310' FNL & 1830' FEL (Unit letter G)

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3169.40' DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON*

CHANGE PLANS

Plug & Abandon

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

TD 8016', PBD 7941'. Present perms 7829-7938'.
13-3/8" OD casing set @ 621'. Cmt circ to surface.
8-5/8" OD casing set @ 3897'. Cmt circ to surface.
5-1/2" OD casing set @ 8016'. TOC @ 4590'.

Propose to P&A in the following manner:

1. Run cmt retr on tbh & set @ 7800'.
2. Cmt below retr w/60 sx Cl C cont'g 4% gel.
3. Load hole w/heavy mud.
4. Cut off 5 1/2" csg as indicated by free pt @ approx 4400' & recover.
5. Spot 40 sk cmt plug half in and half out 5 1/2" csg stub.
6. Spot 40 sk cmt plug across 8-5/8" csg shoe.
7. Spot 40 sk cmt plug across 13-3/8" csg shoe.
8. Spot 10 sk cmt plug @ surface.
9. Install regulation dry hole marker, clean & level location.

AMENDMENT: Additional Cement Plugs @
40 sx. from 5700-6000 feet.
40 sx. from 1100-1275 feet.
The plug @ 621' may be eliminated.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE Dist. Drlg. Supv.

DATE 4/15/75

(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY:

APPROVED

*See Instructions on Reverse Side

APR 17 1975
JIM SIMS
DISTRICT ENGINEER