- 6. <u>Source of Construction Materials</u>: Where possible, material-in-place will be used for upgrading the road and construction of the well pad. If additional material is required, it will be obtained from a caliche pit located on the lease just East of the location owned by J. T. Crawford.
- 7. <u>Method of Handling Waste Disposal:</u>
  - A. Pits will be dug a minimum of 4' below ground level and lined.
  - B. Drill cuttings will be disposed of in the pits.
  - C. Drilling fluids will be allowed to evaporate in the drilling pits until the pits are dry.
  - D. Water produced during test will be disposed of in the drilling pits.
  - E. Plastic lining of the pits will be removed before reclaiming the pit area.
  - F. Trash, waste paper garbage and junk will be stored in an above ground container, emptied when full and taken to an authorized landfill or other suitable disposal facility. At the conclusion of well completion operations, or plugging operation in the case of a dry hole, the trash and debris containers shall be removed from the location.
- 8. <u>Ancillary Facilites:</u> None anticipated.
- 9. <u>Wellsite Layout:</u>
  - A. The dimensions and relative location of the drill pad, mud pit and trash container with respect to the well bore are shown on Exhibit "D".
  - B. Four inches of top soil will be removed from the surface and stockpiled on southwest corner of location. Four inches of cliche will be used for surfacing of location.

## 10. <u>Plans for Restoration of the Surface:</u>

A. After completion of drilling and/or completion operations, all equipment and other material not needed for operations will be removed. Pits will be filled and the location cleaned of all trash and junk to leave the well site in as aesthetically pleasing condition as possible.