

COOPER JAL UNIT WELL NO. 125
JALMAT TANSILL YATES SEVEN RIVERS QUEEN
LANGLIE MATTIX SEVEN RIVERS QUEEN FIELDS
LEA COUNTY, NEW MEXICO

Continuation of Form C-101

9. Pull packer.
10. Clean out to TD of 3655'.
11. Run production equipment. Place on production.
12. Establish 24 hour productivity test.
13. MIRU. Pull rods and pump. Install BOP. Tag bottom and pull tubing. Clean out if necessary.
14. TIH w/5-1/2" RBP and set @ 3410'. Dump 10' sand on top. Pressure test casing to 500 PSI. Pull tubing.
15. GIH w/3-1/8" casing gun and perforate Jalmat as follows:
3035, 40, 44, 48, 52, 57, 62, 64, 68, 74, 80, 84, 88, 92,
98, 3102, 20, 26, 37, 50, 56, 68, 78, 90, 96, 3202, 08, 13,
18, 25, 30, 40, 51, 69, 74, 87, 94, 96, 98, 3356, 58, and
60. 2 JSPI. 84 Holes.
16. TIH w/5-1/2" packer and set @ 2980'.
17. Acidize Jalmat perms w/5,000 gallons 15% NEFE HCL w/150 ball sealers in 4 equal stages. SI 1/2 hour. Swab back load.
18. Fracture perforations 3035'-3360' w/40,000 gallons 40 LB. cross-linked gelled water and 75,000 LBS. 12/20 sand. Rate 20 BPM. Maximum Pressure 4500 PSI.
19. Pull packer. Circulate sand off RBP and retrieve RBP.
20. Run production equipment. Place on production.
21. Test and submit to Hobbs NMOCDC for commingling authority as per test.