

RECEIVED
Form 100-5
(June 1990)

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

FORM APPROVED
Budget Bureau No. 1004-0135
Expires: March 31, 1993

JUL 27 10 40 AM '92

SUNDRY NOTICES AND REPORTS ON WELLS

DO NOT use this form for proposals to drill or to deepen or reentry to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals

SUBMIT IN TRIPLICATE

1. Type of Well

☒ Oil Well ☐ Gas Well ☐ Other

2. Name of Operator

CONEST ENERGY Corporation

3. Address and Telephone No.

2401 Fountain View, Suite 700, Houston, TX 77057

4. Location of Well (Footage, Sec., T., R., M., or Survey Description)

660 FNL & 660 FWL, Sec. 35, T24S-R36E

5. Lease Designation and Serial No.

NMLCO 32618A

6. If Indian, Allottee or Tribe Name

7. If Unit or CA, Agreement Designation

8. Well Name and No.

I. B. Cgg A #4

9. API Well No.

3002509703005T ✓ API Connected

10. Field and Pool, or Exploratory Area

JALMAT T-Y-SR

11. County or Parish, State

LEA County
NEW MEXICO

12. CHECK APPROPRIATE BOX(S) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

TYPE OF SUBMISSION

- ☒ Notice of Intent
☐ Subsequent Report
☐ Final Abandonment Notice

TYPE OF ACTION

- ☒ Abandonment
☐ Recompletion
☐ Plugging Back
☐ Casing Repair
☐ Altering Casing
☐ Other

- ☐ Change of Plans
☐ New Construction
☐ Non-Routine Fracturing
☐ Water Shut-Off
☐ Conversion to Injection
☐ Dispose Water

(Note: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

- 1) Notify BLM @ (505) 393-3612
- 2) ME & RU Rig. Pool w/ Production Est. + LD All except tbg.
- 3) Set CIBP @ 3300'. Spot 35' cement on top of BP @ /-level.
- 4) Displace hole w/ 9.0 ppg. mud.
- 5) Perf 7" csg. @ 1667'.
- 6) Set 100' cement Plug in + outside 7" csg. TAG PLUG.
- 7) Perf 9 5/8" csg. @ 225'.
- 8) Spot 100' cement Plug in + outside of 9 5/8" csg.
- 9) Cut off csgs. 4' below ground. Weld on plate + Marker w/ I.D. Sign.
- 10) Level & Restore Location.

CEMENT SLURRY USED IN THIS PROCEDURE SHALL BE CLASS "C" WITH
2% CaCl₂ MIXED AT 14.8 PPG.

14. I hereby certify that the foregoing is true and correct

Signed

Ed Stendup

Title

Agent

Date

7/20/92

(This space for Federal or State office use)

Approved by

Adam S. Cane

Title

Date

8/10/92

Conditions of approval, if any: