

**SMU #1 ACID STIMULATION**  
**RECOMMENDED PROCEDURE**

1. MIRU pulling unit. Kill well and POH with rods, pump and tubing.
2. PU 7 inch packer and RIH with tubing to depth of 9350 feet. Set packer and apply 500 psig to backside.
3. RU HES and acidize open hole Ellenberger Formation with 10,000 gals of gelled acid with diverter as per program to be issued.
4. POH with tubing and packer.
5. Rerun tubing, anchor, rods and pump. Hang well on beam. RDMO.
6. Production test well reporting results to Houston Office

RECEIVED  
MAY 01 2000  
BLM  
ROSWELL NM