

NEW MEXICO OIL CONSERVATION COMMISSION  
SANTA FE, NEW MEXICO

**MISCELLANEOUS NOTICES**

Submit this notice in triplicate to the Oil Conservation Commission or its proper agent before the work specified is to begin. A copy will be returned to the sender on which will be given the approval, with any modifications considered advisable, or the rejection by the Commission or agent, of the plan submitted. The plan as approved should be followed, and work should not begin until approval is obtained. See additional instructions in the Rules and Regulations of the Commission.

Indicate nature of notice by checking below:

NOTICE OF INTENTION TO TEST CASING SHUT-OFF		NOTICE OF INTENTION TO SHOOT OR CHEMICALLY TREAT WELL	
NOTICE OF INTENTION TO CHANGE PLANS		NOTICE OF INTENTION TO PULL OR OTHERWISE ALTER CASING	
NOTICE OF INTENTION TO REPAIR WELL		NOTICE OF INTENTION TO PLUG WELL	
NOTICE OF INTENTION TO DEEPEN WELL		<b>Plug and Abandon</b>	<b>XX</b>
		<b>Hobbs, New Mexico</b>	<b>March 18, 1952</b>
		Place	Date

OIL CONSERVATION COMMISSION,  
Santa Fe, New Mexico

Gentlemen:

**Gulf Oil Corporation** intention to do certain work as described below at the 1 SW SE  
 Comp. 16 or Operator 243 37E Lease Langlie-Matrix in  
 of Sec. Lea, T. \_\_\_\_\_, R. \_\_\_\_\_, N. M. P. M. \_\_\_\_\_ Field.  
 \_\_\_\_\_ County.

FULL DETAILS OF PROPOSED PLAN OF WORK

FOLLOW INSTRUCTIONS IN THE RULES AND REGULATIONS OF THE COMMISSION  
**Total Depth 3548'. 7" 24# Casing set at 3395'. 10-3/4" 32.75# Casing set at 232'. Open hole size 6-1/4". 8-3/4" hole 239'-3400'. Rustler formation 1070' 1170'. Top salt 1170'. Base salt 2440'. Queen formation 3310'-3548'.**

Recommended Procedure

1. Load hole with mud.
2. Pull tubing.
3. Rerun tubing with Baker Model "K" cement retainer. Set retainer in the 7" 24# casing at 3380' and squeeze below with 50 sacks cement.
4. Shoot off 7" casing at approximately 2300' and pull same.
5. Place a cement plug from 1200' to 1100' in the 8-3/4" open hole. 25 sax cement.
6. Place a cement plug from 1100' to 1050' in the 8-3/4" open hole. 25 sax cement.
7. Plug back 25' to the surface inside the 10-3/4" casing. 13 sacks cement.
8. Install 4" x 4' marker, fill cellar and clear location.

Gulf Oil Corporation

Approved \_\_\_\_\_, 19\_\_\_\_\_  
 except at follows:

By Charles Jay Area Prod. Supt.  
 Position \_\_\_\_\_  
 Send communications regarding well to **Gulf Oil Corporation**  
 Name Box 2167, Hobbs, New Mexico  
 Address \_\_\_\_\_

OIL CONSERVATION COMMISSION,  
 By R. J. Blynn  
 Title \_\_\_\_\_