


PLUGGING PROCEDURE - GULF - J. R. HOLT NO. 1




1. Fill hole full of mud.
2. Set Baker Model "K" Cement Retainer in 7" casing at 3380' and plug back below retainer from 3548' to 3380'.
40 sacks cement
3. Shoot off 7" casing at approximately 2300'.
4. Pull 2300' of 7" OD casing.
5. Place Calseal plug from 1120' to 1145'. 8 3/4" hole.
8 sacks Calseal
6. Let Calseal set. Plug back from 1095' to 1120' With cement. 8 3/4" hole.
9 sacks cement
7. Place bridge 25' down inside 10 3/4" casing.
8. Fill top 25' of 10 3/4" casing with cement.
13 sacks cement
9. Surface cement plug.
5 sacks cement
10. Place 4" pipe marker inside 10 3/4" casing and extending 4' above mean ground level.

67 sacks cement

8 sacks calseal

APR 26 1951



TO THE HONORABLE
MEMBERS OF THE
COMMISSION
FROM THE
HOBBS OFFICE
OIL CONSERVATION COMMISSION
APR 1 1951

APR 5 1951