

OIL CONSERVATION DIVISION

P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-3421	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator Gulf Oil Corporation		8. Farm or Lease Name J. R. Holt (NCT-A)
3. Address of Operator P. O. Box 670, Hobbs, NM 88240		9. Well No. 2
4. Location of Well UNIT LETTER <u>N</u> <u>660</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM THE <u>West</u> LINE, SECTION <u>16</u> TOWNSHIP <u>24S</u> RANGE <u>37E</u> NMPM.		10. Field and Pool, or Wildcat Jalmat Langlie Mattix
15. Elevation (Show whether DF, RT, GR, etc.) 2245' GL		12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐
PULL OR ALTER CASING ☐
OTHER ☐

PLUG AND ABANDON ☒
CHANGE PLANS ☐
OTHER ☐

REMEDIAL WORK ☐
COMMENCE DRILLING OPNS. ☐
CASING TEST AND CEMENT JOBS ☐
OTHER ☐

ALTERING CASING ☐
PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Cut tubing if necessary, POH with tubing. Set CIBP 20' above tubing fish or 2945'. Cap with 35' cement. Set CIBP at 2625', cap with 35' cement. Circulate hole with abandonment mud. Perf 1190' with (4) 1/2" 90° phased JH. Establish circulation. Set cement retainer at 1140', test tubing 3000#. Pump 500 sacks Class "C" neat. If cement circulates, close surface valve and squeeze. Dump 35' cement on cement retainer and spot plug 202'-302'. If cement not circulated, run temperature survey and establish top of cement. If top of cement is 200' or higher, spot cement plug 302'-202'. If top of cement is below 250', perf at top or cement or 300' with (4) 1/2" 90° phased JH. Set cement retainer at 200'. Pump 200 sacks Class "C" neat cement, circulate and squeeze. Dump 35' cement on retainer. Spot 50' surface plug. Install dry hole marker. Clean and clear location.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED R. D. Pite TITLE Area Engineer DATE 9-21-82

ORIGINAL SIGNED BY JERRY LINTON TITLE DATE SEP 24 1982
APPROVED BY CONDITIONS OF APPROVAL