


GULF OIL CORPORATION

PLUGGING PROCEDURE - J. E. HOLT NO. 2



1. Fill hole full of mud.
2. Set Baker Model "K" Cement Retainer in 6" casing at 3375' and plug back below retainer from 3550' to 3375'.
38 sacks cement
3. Shoot off 6" OD casing at 2370'
4. Pull 2370' of 6" OD casing.
5. Place Calseal Plug from 1140' to 1165'. 7 7/8" hole.
8 sacks Calseal
6. Let Calseal set. Plug back from 1115' to 1140' with cement 7 7/8" hole.
8 sacks cement
7. Place bridge 25' down inside 9 5/8" casing.
8. Fill top 25' of 9 5/8" casing with cement. 10 sacks cement
9. Surface cement plug.
5 sacks cement
10. Place 4" pipe marker inside 9 5/8" casing and extending 4' above mean ground level.

61 sacks cement

8 sacks calseal

Oil & Gas Inspector

