

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT - M" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator McCulloch Oil Corporation	8. Term or Lease Time Hair
3. Address of Operator 2000 Classen Center, Suite 614-East, Oklahoma City, Okla. 73100	9. Well No. 1
4. Location of Well UNIT LETTER <u>M</u> <u>554</u> FEET FROM THE <u>South</u> LINE AND <u>554</u> FEET FROM THE <u>West</u> LINE, SECTION <u>11</u> TOWNSHIP <u>24-S</u> RANGE <u>37-E</u> NMPM.	10. Field and Pool, or Wildcat Fowler (Upper Yeso)
15. Elevation (Show whether DF, RT, GR, etc.) 3223' GL; 3234' KB	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input checked="" type="checkbox"/>	OTHER <input type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- 4-21-76 1. Run tubing to 5350' Spot 15 sacks cement
- 4-22-76 2. Attempt to tag plug. Cement went away
- 4-22-76 3. Run cast iron Bridge Plug & Set at 5,300" Spot 10 sacks cement 5300 to 5212
- 4-24-76 4. Pull 2500' 5-1/2 casing
- 4-26-76 5. Run tubing to 2515, spot 50 sacks cement from 2515 to 2341 (In & out of 5-1/2 casing stub)
- 4-26-76 6. Pull tubing to 1200', spot 50 sacks cement from 1200 to 1027 (In & out of bottom of 8-5/8")
- 4-26-76 7. Pull tubing to 60', pump 20 sacks cement from 60 circulate to surface
- 4-26-76 8. Install dry Hole marker, Clean location

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Dwaine Hardy (D.A.S.)</u>	TITLE <u>Pusher</u>	DATE <u>5-11-76</u>
APPROVED BY <u>Charles W. Johnson</u>	TITLE <u>Geologist</u>	DATE <u>5/27/76</u>
CONDITIONS OF APPROVAL, IF ANY:		