

NEW MEXICO OIL CONSERVATION COMMISSION

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input checked="" type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO CLEAN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator McCulloch Oil Corporation	8. Farm or Lease Name Sh - Hair
3. Address of Operator 2000 Classen Bldg, Suite 614-East, Oklahoma City, Okla. 73106	9. Well No. 11
4. Location of Well UNIT LETTER <u>D</u> <u>554</u> FEET FROM THE <u>North</u> LINE AND <u>554</u> FEET FROM THE <u>West</u> LINE, SECTION <u>11</u> TOWNSHIP <u>24-S</u> RANGE <u>37-E</u> NMPM.	10. Field and Pool, or Wildcat Fowler (Upper Yesso)
15. Elevation (Show whether DF, RT, GR, etc.) 3221' Gr; 3231' KB	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1603.

- 4-29-76 1. Run tubing to 6110, Spot 50 sacks cement from 6110' to 5937'
- 4-29-76 2. Pull tubing to 5525, Spot 50 sacks cement from 5525' to 5352'
- 4-29-76 3. Pull tubing to 5155, Spot 50 sacks cement from 5155' to 4972'
- 4-29-76 4. Pull tubing to 4377, Spot 50 sacks cement from 4377' to 4204'
- 4-30-76 5. Pull tubing to 3572, Spot 50 sacks cement from 3572' to 3399'
- 4-30-76 6. Pull tubing to 2260, Spot 50 sacks cement from 2260' to 2087'
- 4-30-76 7. Pull tubing to 1167, Spot 50 sacks cement from 1167' to 994' (8-5/8" Set @ 1117')
- 4-30-76 8. Pull tubing to 60' pump 20 sacks cement & Circulate to surface.
- 4-30-76 9. Install Dry Hole Marker Clean Location.

Expire 6/1/77

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>Duane Hardy (D.A.45)</u>	TITLE <u>Pusher</u>	DATE <u>5-11-76</u>
APPROVED BY <u>Charles Walker</u>	TITLE <u>Geologist</u>	DATE <u>5-27-76</u>
CONDITIONS OF APPROVAL, IF ANY:		