

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

CONSERVATION DIVISION  
P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

3a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-2431	

<p align="center"><b>SUNDRY NOTICES AND REPORTS ON WELLS</b></p> <p align="center"><small>(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)</small></p>		
<p>1. <input type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-</p>		7. Unit Agreement Name
2. Name of Operator		8. Farm or Lease Name
Gulf Oil Corporation		J. R. Holt (NCT-A)
3. Address of Operator		9. Well No.
P. O. Box 670, Hobbs, NM 88240		5
4. Location of Well		10. Field and Pool, or Wildcat
UNIT LETTER <u>0</u> , <u>810</u> FEET FROM THE <u>South</u> LINE AND <u>1980</u> FEET FROM THE <u>East</u> LINE, SECTION <u>16</u> TOWNSHIP <u>24S</u> RANGE <u>37E</u> NMPM.		Langlie Mattix
15. Elevation (Show whether DF, RT, GR, etc.)		12. County
3235' GL		Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

POH with tubing. Set CIBP at 3240'. Circulate hole. Cap CIBP with 35' cement. Spot 100' plug 2397'-2297'. Spot 100' plug 1250'-1150'. Tag plug at 1150'. Perf casing at 1140' with (4) 1/2" 90° JH. Open surface valve and pump down casing. Set cement retainer at 1079'. Pump 350 sacks Class "C" with Halad 9. Circulate cement. Close surface valve and squeeze. Spot 50' surface plug. Install dry hole marker. Clean and clear location. P&A 4-21-83.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.		
SIGNED <u>R.D. Prite</u>	TITLE <u>Area Engineer</u>	DATE <u>5-6-83</u>
APPROVED BY <u>Alt. J. J. J. J. J.</u>	TITLE <u>OIL &amp; GAS INSPECTOR</u>	DATE <u>MAY 6 1983</u>
CONDITIONS OF APPROVAL, IF ANY:		

RECEIVED  
MAY 6 1983  
O.G.O.  
HARRIS OFFICE