



MITCHELL ENERGY CORP.

Well Plan

ANASAZI / SCHARBAUER AREA

Lea County. New Mexico

WELL DATA

Company: Mitchell Energy Corporation
Field: West Teas
Objective: Yates
Total Depth: 3600'

TABLE OF CONTENTS

Section Title:	Section No.
Well Data	1.0
Drilling Prognosis	2.0
Drilling Program	3.0
Mud Program	4.0
Casing String Design	5.0
Cementing Program	6.0
BOP Diagrams	7.0

DRILLING PROGNOSIS

FIELD: West Teos

WELL: Anasazi/Scharbauer Area

OBJECTIVE: Yates

ELEVATION:

GEOLOGICAL

MECHANICAL

Ditch Cuttings	Logging Program	Formation Tops	Well Depth	Hole Size	Casing & Cement	Mud Program	Hole Dvtn
NONE	NONE	GR/CNL RUSTLER 1340'	1350'	12-1/4"	8-5/8" 24# K-55 Cement to Surface	Fresh Water Spud Mud	2 Deg. Maximum Allowed
	Run #1 GR/DLL/MSFL GR/CNL/LDT			7-7/8"	4-1/2" 10.5# K-55 W/ Combination Tool (DV tool + External Casing Packer) • 2950' Cemented in Two Stages 1st Stage TOC = 2950' 2nd Stage TOC = Surface	Saturated Brine Water	3 Deg. Maximum Allowed
		Base of Salt 2810'					
		YATES 3170'					
2 Man Unit Samples Every 10'			3600'				

DRILLING PROGRAM

- 1.0 Set conductor at +/- 40' with rat hole machine.
- 2.0 Move in drilling rig and rig up same.
- 3.0 Drill 12-1/4" hole to +/- 1350'.
- 4.0 At 1350' circulate and condition hole for casing.
- 5.0 Run 8-5/8" casing as shown on the appropriate attachment, "Casing String Design".
 - 5.1 Once casing string is made up, circulate a minimum of one entire circulation while reciprocating casing.
- 6.0 Cement 8-5/8" casing as per attached cement program.
- 7.0 Cut off conductor and 8-5/8" casing and install 11" x 3MWP head as shown on attachment.
- 8.0 Nipple up 11" x 3MWP - BOP stack as shown on attachment.
- 9.0 Test annular BOP to 1000 psi. Test rams, choke manifold and all associated equipment to 1000 psi.
- 10.0 Drill 7-7/8" hole to +/- 3600'.
 - 10.1 Prior to drilling the float collar, pressure test the casing to 600 psi by closing the annular preventer and pressuring up to 600psi. Hold this pressure for a minimum of 30 minutes and record any pressure fluctuations. Report the results of this test on the morning report.
- 11.0 At 3600', condition hole for logs and log well as per attached "Geological Prognosis".
- 12.0 Following logging operations, trip back in hole and circulate a minimum of one complete circulation. Have the mud engineer perform a full check during this circulation and verify mud is in condition to run casing.
- 13.0 Once the order has been given to run pipe and the above conditions have been met, begin the trip out of the hole laying down the drill string to run casing.


14.0 Make up and run 4 1/2" casing as per the following:

- A. Clean exposed threads on the guide shoe, first joint of 4 1/2" casing, float collar, and second joint of casing.
 - B. Apply thread lock to the above listed connections prior to make-up.
 - C. The bottom assembly of the casing assembly must be made up as follows with the first listed being the first in the hole:
 - 1. Guide shoe
 - 2. First joint of 4 1/2" casing
 - 3. Float collar
 - 4. 4 1/2" casing back to setting depth of 2950' (140' below the salt).
 - 5. Combination Tool (DV Tool with External Casing Packer)
 - 6. 4-1/2" casing back to surface.
 - D. Install centralizers as follows on the 4-1/2" casing:
 - 1. 10' above the guide shoe by means of a stop collar.
 - 2. Around the first coupling above the float collar.
 - 3. Every third coupling back to the combination tool.
 - 4. Around the coupling immediately below the combination tool.
 - 5. Around the coupling immediately above the combination tool.
 - 6. Every third coupling back to surface.
15. With casing on bottom, circulate mud a minimum of one circulation. Monitor returns to ensure hole is "clean".
16. Cement the 4 1/2" casing string as follows:
- A. Reciprocate the casing during the first stage circulation and cementation.
 - B. Once the first stage cement is in place (Figure 1), drop the **EXTERNAL CASING PACKER / DV TOOL ACTUATION DEVICE** (a.k.a. Ball, Bomb, Plug, Dart (Figure 2)).
 - C. With guidance from the tool manufacturers representative, set the external casing packer and open the DV tool.
 - D. Circulate one complete circulation through the DV tool to ensure any residual cement from the first stage is removed from the annulus above the combination tool.
 - E. Pump the second stage cement into position followed by the **SECOND STAGE FOLLOWING PLUG**. Displace cement and plug with drilling fluid. The **SECOND STAGE FOLLOWING PLUG** will close the DV tool ports when the cement is in place (Figure 3).

17. Set the slips on the 4 1/2" casing in the as cemented condition.
18. Install the "Bell Nipple" tubing head, and associated equipment comprising the B" section.
19. Once all contractual obligations are met, release the rig.
20. **!!!!!!!!!!!! -- NET THE PITS -- !!!!!!!!!!!!!!!**

Wellbore Schematic

First Stage Cement In Place




WCT

Figure 1


Wellbore Schematic

DISPLACING SECOND STAGE CEMENT



Wellbore Schematic

SECOND STAGE CEMENT IN PLACE



MUD PROGRAM

<i>Depth Interval (feet)</i>	<i>Density PPG)</i>	<i>Funnel Viscosity (Seconds)</i>	<i>Type Mud</i>	<i>Filtrate (cc)</i>
0-1350'	8.5	40-45	Spud Mud	NC
1350'-3600'	10.0	28	Saturated Brine Water	NC

CASING STRING DESIGN

DEPTH: 1350'
 TYPE: Surface
 SIZE: 8-5/8"
 MUD WEIGHT: 8.5

<i>Description</i>	<i>Interval</i>	<i>Length Per Section</i>	<i>Weight Per Section</i>	<i>Cumm. Weight</i>	<i>Min. Strength</i>	<i>Tens. S.F.</i>
24#,ST&C,K-55	0-1350'	1350'	32400#	32400#	263,000	8.12

<i>Collapse Force</i>	<i>*Resist</i>	<i>S.F.</i>	<i>Burst Force</i>	<i>Resist.</i>	<i>S.F.</i>	<i>Minimum Torque</i>	<i>Optimum Torque</i>	<i>Maximum Torque</i>
596	1370	2.29	624	2950	4.72	1970	2630	3290

* Tension effect on collapse resistance included

Procedure:

1. Clean threads on shoe joint , float collar, and guide shoe to bare shiny metal. Apply Thread Lock to connections prior to make-up.
2. The casing assembly will be made up as follows:

Note: Best-o-Life 2000 will be applied to all connections not receiving Thread Lock.

- a. Guide shoe
 - b. Shoe Joint
 - c. Float collar
 - d. Remainder of casing string
-
3. Centralizers should be applied 10 feet above the guide shoe by means of a stop collar, around the first coupling above the float collar, and every fourth coupling back to surface.

CASING STRING DESIGN

DEPTH: 3600'
 TYPE: Production
 SIZE: 4-1/2"
 MUD WEIGHT: 10.0

<i>Description</i>	<i>Interval</i>	<i>Length Per Section</i>	<i>Weight Per Section</i>	<i>Cumm. Weight</i>	<i>Min. Strength</i>	<i>Tens. S.F.</i>			
10.5#,LT&C,K-55	0-3600'	3600'	37,800#	37,800#	146K	3.86			
<i>Collapse Force</i>	<i>Resist</i>	<i>S.F.</i>	<i>Burst Force</i>	<i>Resist.</i>	<i>S.F.</i>	<i>Minimum Torque</i>	<i>Optimum Torque</i>	<i>Maximum Torque</i>	
1872	4010	2.14	1740	4790	2.75	1100	1460	1825	

Procedure:

Make up and run 4 1/2" casing as per the following:

A. Clean exposed threads on the guide shoe, first joint of 4 1/2" casing, float collar, and second joint of casing. Apply Thread Lock to these connections prior to make-up.

B. The bottom assembly of the casing assembly must be made up as follows with the first listed being the first in the hole:

Note: Seal Lube will be applied to all connections not receiving Thread Lock.

1. Guide shoe
2. First joint of 4 1/2" casing
3. Float collar
4. 4 1/2" casing back to setting depth of 2950' (140' below the salt).
5. Combination Tool (DV Tool with External Casing Packer)
6. 4-1/2" casing back to surface.

C. Install centralizers as follows on the 4-1/2" casing:

1. 10' above the guide shoe by means of a stop collar.
2. Around the first coupling above the float collar.
3. Every third coupling back to the combination tool.
4. Around the coupling immediately below the combination tool.
5. Around the coupling immediately above the combination tool.
6. Every third coupling back to surface.

Cementing Program

8-5/8" Surface Casing

Depth:	1350'
Casing Size:	8-5/8"
Hole Size:	12.25"
Calculated Cement Fill:	1350'
Excess Calculated:	100%
Cementing Company:	Halliburton

Cement Recommendation:

Spacer: 20 Bbls Fresh Water

Slurry: 860 sacks Premium Plus + 2% CaCl₂

Slurry Weight:	14.8 ppg
Slurry Yield:	1.34 cu.ft./sack

Procedure:

1. Utilize the two-plug system.
2. Wait on cement a minimum of 8 hours.

NOTE: VOLUME ADJUSTMENTS BASED ON THE CALIPER WILL BE UNATTAINABLE. THE STANDARD PRACTICE FOR SURFACE CASING CEMENT VOLUME DETERMINATION HAS BEEN CALCULATED (GAUGE HOLE PLUS 100% EXCESS). NO FURTHER CALCULATIONS WILL BE MADE FOR CEMENT VOLUME.

Cementing Program

4-1/2" Production Casing

Depth:	3600'
Casing Size:	4-1/2"
Hole Size:	7-7/8"
Calculated Cement Fill:	3600' (In Two Stages)
Excess Calculated	
1st Stage:	15% over caliper
2nd Stage:	100%
Cementing Company:	Halliburton

Cement Recommendation:

1st Stage:

Slurry: 150 sacks Premium Plus + 2.5 #/sk Salt (Accelerator) + 0.4% HALAD-322 (Fluid Loss)

Slurry Weight:	14.8 ppg
Slurry Yield:	1.36 cu.ft./sack

2nd Stage:

Lead Slurry: 720 sacks Premium Plus + 1% CaCl₂ + 15 #/sk Salt

Slurry Weight:	14.0 ppg
Slurry Yield:	1.75 cu.ft./sack

Tail Slurry: 80 sacks Premium Plus

Slurry Weight:	14.8 ppg
Slurry Yield:	1.32 cu.ft./sack

Procedure:

Cement the 4 1/2" casing string as follows:

- A. Reciprocate the casing during the first stage circulation and cementation.

Cementing Program

4-1/2" Production Casing Continued

- B. Once the first stage cement is in place (Figure 1), drop the **EXTERNAL CASING PACKER / DV TOOL ACTUATION DEVICE** (a.k.a. Ball, Bomb, Plug, Dart) .
- C. With guidance from the tool manufacturers representative, set the external casing packer and open the DV tool.
- D. Circulate one complete circulation through the DV tool to ensure any residual cement from the first stage is removed from the annulus above the combination tool.
- E. Pump the second stage cement into position followed by the **SECOND STAGE FOLLOWING PLUG**. Displace cement and plug with drilling fluid. The **SECOND STAGE FOLLOWING PLUG** will close the DV tool ports when the cement is in place

MINIMUM BLOWOUT PREVENTER REQUIREMENTS

3,000 psi Working Pressure

3 MWP


STACK REQUIREMENTS

No.	Item	Min. i.D.	Min. Nominal
1	Flowline		
2	Fill up line		2"
3	Drilling nipple		
4	Annular preventer		
5	Two single or one dual hydraulically operated rams		
6a	Drilling spool with 2" min. kill line and 3" min choke line outlets		
6b	2" min. kill line and 3" min. choke line outlets in ram. (Alternate to 6a above.)		
7	Valve Gate <input type="checkbox"/> Plug <input type="checkbox"/>	3-1/8"	
8	Gate valve—power operated	3-1/8"	
9	Line to choke manifold		3"
10	Valves Gate <input type="checkbox"/> Plug <input type="checkbox"/>	2-1/16"	
11	Check valve	2-1/16"	
12	Casing head		
13	Valve Gate <input type="checkbox"/> Plug <input type="checkbox"/>	1-13/16"	
14	Pressure gauge with needle valve		
15	Kill line to rig mud pump manifold		2"

OPTIONAL

16	Flanged valve	1-13/16"	
----	---------------	----------	--

CONFIGURATION A



CONTRACTOR'S OPTION TO FURNISH:

1. All equipment and connections above bradenhead or casinghead. Working pressure of preventers to be 3,000 psi, minimum.
2. Automatic accumulator (80 gallon, minimum) capable of closing BOP in 30 seconds or less and, holding them closed against full rated working pressure.
3. BOP controls, to be located near drillers position.
4. Kelly equipped with Kelly cock.
5. Inside blowout preventer or its equivalent on derrick floor at all times with proper threads to fit pipe being used.
6. Kelly saver-sub equipped with rubber casing protector at all times.
7. Plug type blowout preventer tester.
8. Extra set pipe rams to fit drill pipe in use on location at all times.
9. Type RX ring gaskets in place of Type R.

MEC TO FURNISH:

1. Bradenhead or casinghead and side valves.
2. Wear bushing, if required.

GENERAL NOTES:

1. Deviations from this drawing may be made only with the express permission of MEC's Drilling Manager.
2. All connections, valves, fittings, piping, etc., subject to well or pump pressure must be flanged (suitable clamp connections acceptable) and have minimum working pressure equal to rated working pressure of preventers up through choke. Valves must be full opening and suitable for high pressure mud service.
3. Controls to be of standard design and each marked, showing opening and closing position.
4. Chokes will be positioned so as not to hamper or delay changing of choke beans. Replaceable parts for adjustable choke, other bean sizes, retainers, and choke wrenches to be conveniently located for immediate use.
5. All valves to be equipped with handwheels or handles ready for immediate use.
6. Choke lines must be suitably anchored.

7. Handwheels and extensions to be connected and ready for use.
8. Valves adjacent to drilling spool to be kept open. Use outside valves except for emergency.
9. All seamless steel control piping (3000 psi working pressure) to have flexible joints to avoid stress. Hoses will be permitted.
10. Casinghead connections shall not be used except in case of emergency.
11. Do not use kill line for routine fill-up operations.

Submit to Appropriate
District Office
State Lease - 4 copies
Fee Lease - 3 copies

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-102
Revised 1-1-89

OIL CONSERVATION DIVISION

P.O. Box 2088
Santa Fe, New Mexico 87504-2088

DISTRICT I
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

WELL LOCATION AND ACREAGE DEDICATION PLAT

All Distances must be from the outer boundaries of the section

Operator MITCHELL ENERGY		Lease ANASAZI 4 STATE		Well No. #9
Unit Letter M	Section 4	Township 20S.	Range 33E.	County LEA
Actual Footage Location of Well: 330 feet from the SOUTH line and 660 feet from the WEST line				
Ground level Elev. 3554	Producing Formation Yates/Seven Rivers		Pool West Teas	Dedicated Acreage: 40 Acres

1. Outline the acreage dedicated to the subject well by colored pencil or hatchure marks on the plat below.
2. If more than one lease is dedicated to the well, outline each and identify the ownership thereof (both as to working interest and royalty).
3. If more than one lease of different ownership is dedicated to the well, have the interest of all owners been consolidated by communitization, unitization, force-pooling, etc.?
- ☐ Yes ☐ No If answer is "yes" type of consolidation _____
- If answer is "no" list the owners and tract descriptions which have actually been consolidated. (Use reverse side of this form if necessary.)
- No allowable will be assigned to the well until all interests have been consolidated (by communitization, unitization, forced-pooling, or otherwise) or until a non-standard unit, eliminating such interest, has been approved by the Division.

SECTION 4, T.20S., R.33E., N.M.P.M.

660'

330'

OPERATOR CERTIFICATION

I hereby certify that the information contained herein is true and complete to the best of my knowledge and belief.

Signature

Printed Name

George Mullen

Position

Regulatory Affairs Specialist
Company

Mitchell Energy Corporation

Date

October 22, 1993

SURVEYOR CERTIFICATION

I hereby certify that the well location shown on this plat was plotted from field notes of actual surveys made by me or under my supervision, and that the same is true and correct to the best of my knowledge and belief.

Date Surveyed

7/27/93

Signature & Seal of
Professional Surveyor

6290

REGISTERED SURVEYOR

6290

Certificate No.

6290

RESETSZ1